





Art. Nr. 2966 5714

LKZ 41164




- | | |
|---|-------------------------------------|
| (D) Montageanleitung | (GB) Assembly instructions |
| (FR) Notice de montage | (IT) Istruzioni di montaggio |
| (NL) Handleiding voor de montage | (PL) Instrukcja montazu |
| (CZ) Montážní návod | (SK) Návod na montáž |
| (HU) Szerelési útmutató | (RO) Instruktiuni de montaj |
| (TR) Montaj talimati | (RU) Инструкция по монтажу |





A 000083  M6x12 x8	B 253901  M6x20 x8	C 007085  M6 x4	D 230041  22x16 x4	E 191303  x4
---	---	--	---	--

N	Size/MaB (mm)	Qty	✓
1	1200x752x22	1	
2	651x746x30	2	
3	651x746x30	2	
4	187x119x25	1	





Service - Dienstverlening - Serwis - Servis - Сервисная служба



Name - Naam - Nazwa - Isim - Название

Nr. - No. - Номер


Typ - Type - Тип - Тип







1
x2





2



B	M6x20
253901	 x8
D	22x16
230041	 x4



4



5

