








- | | |
|---|-------------------------------------|
| (D) Montageanleitung | (FR) Notice de montage |
| (NL) Handleiding voor de montage | (CZ) Montážní návod |
| (HU) Szerelési útmutató | (TR) Montaj talimatı |
| (GB) Assembly instructions | (IT) Istruzioni di montaggio |
| (PL) Instrukcja montażu | (SK) Návod na montáž |
| (RO) Instrucțiuni de montaj | (RU) Инструкция по монтажу |

Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam •
Nazwa • Jméno • Názov • Név •
Denumire • Ísim • Название

Nr. • No. • N° • Номер • Č • Sz



Typ • Type • Tip • Típus • Tipo •
Тип




A 8,0 x 30 mm 16x	B 16x	C 16x	D 6x	E 3,0 x 12 mm 12x	F 6x	G 4,0 x 20 mm 6x
H 4x	I 4x	J M4,0 x 9 mm 4x	K 2,7 x 20 mm 12x	L 4x	M 6,3 x 13 mm 8x	N 1x
O 8x						

1




A 8,0 x 30 mm 16x	B 16x	C 16x	D !! 6x	E 3,0 x 12 mm 12x	F 6x	G 4,0 x 20 mm 6x
L 4x	M 6,3 x 13 mm 8x					I h=2 4x





2





D Leim
GB Glue
FR Colle
IT Colla
NL Lijm
PL Klej
CZ Lepidlo
SK Glej
HU Enyv
RO Adeziv
TR Tutkal
RU Клей





3




4



5





NL Deuren instellen
(scharnieren afstellen)

D Türen einstellen
(Scharniere justieren)

GB Adjusting the doors
(adjusting the hinges)

FR Régler les portes
(ajuster les charnières)

IT Sistemare le porte
(regolare le cerniere)

PL Nastawić drzwi
(wyregulować zawiasy)

CZ Vyrovnajte dvířka
(seřid'te závěsy)

RO Nastavenie dverí
(nastavenie závesov)

HU Állítsa be az ajtókat
(állítsa be a zsanérokat)

TR Reglare uşi
(ajustare balamale)

SK Kapílarin ayarlanması
(menteşelerin seviye ayarı)

RU Регулировка дверей
(регулировка шарнира)

