

JOHN NEU 2 U-FORM



- DE

Montageanleitung
- PL

Instrukcja montaży
- NL

Handleiding voor de montage
- GB

Assembly instructions
- TR

Montaj talimatı
- RU

Инструкция по монтажу

IT

Istruzioni di montaggio

FR

Notice de montage

RO

Instrucțiuni de asamblare

SK

Montážny návod

CZ

Montážní návod

HU

Szerelési útmutató

Name - Nazwa - Naam - Name - Isim - название
Nome - Nom - Numele - Meno - Jméno - Neve

JOHN 2 U-FORM


1:L



6x (M8x60)	9x (M8x80)	8x (M6x35)	9x (4x16)	8x (5x35)	4x (5x50)	15 x Ø8	15x
a	b	n	f	p	i	d	j
15x M8	12x	1x	4x	12x	2x	7x	
e	k	w	g	r	s	t	







Service - Servis - Dienstverlening - Servis - Serwis - Сервисная служба - Servizio - Service
Serviciu - Služby - Szolgáltatás



Ver: 03.11.16

1 - JOHN 2 U-FORM - L



2 - JOHN 2 U-FORM - L

JOHN NEU 2 U-FORM

(DE) Montageanleitung

(PL) Instrukcja montażu

(NL) Handleiding voor de montage

(GB) Assembly instructions

(TR) Montaj talimatı

(RU) Инструкция по монтажу

(IT) Istruzioni di montaggio

(FR) Notice de montage

(RO) Instrucțiuni de asamblare

(SK) Montážny návod

(CZ) Montážní návod

(HU) Szerelési útmutató



Name - Nazwa - Naam - Name - Isim - название
Nome - Nom - Numele - Meno - Jméno - Neve

JOHN 2 U-FORM


2:P







6x (M8x60)	9x (M8x80)	8x (M6x35)	9x (4x16)	8x (5x35)	4x (5x50)	15 x Ø8	15x
a	b	n	f	p	i	d	j
15x M8	12x	1x	4x	12x	2x	7x	
e	k	w	g	r	s	t	



Service - Servis - Dienstverlening - Servis - Serwis - Сервисная служба - Servizio - Service
Serviciu - Služby - Szolgáltatás



1 - JOHN 2 U-FORM - P



2 - JOHN 2 U-FORM - P

cm 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20



13

