



D Montageanleitung
 GB Assembly instructions
 NL Handleiding voor de montage
 PL Instrukcja montażu
 HU Szerelés útmutató
 RO Instrucțiunile de montaj
FR Notice de montage
 IT Istruzioni di montaggio
 CZ Montážní návod
 SK Návod na montáž
 TR Montaj talimatı
 RU Инструкция по монтажу

Service • Assistenza • Dienstverlening • Servis
Servis • Szerviz • Сервисная служба

Adres: ...
 Telefon: ...
 E-mail: ...
 Web: ...




101	ASL 708x550x15mm	1
2	ASR 735x550x15mm	1
31	MS 708x550x15mm	1
4	BL 1250x600x15mm	1
5	BD 350x550x15mm	1
6	ZB 318x515x15mm	1
7	ZBR 846x515x15mm	1
8	TRA 846x260x15mm	1
9	MSR 90x515x15mm	1
10	TR 414x314x15mm	1
11	SKV 314x157x15mm	1
12	SKB 295x318x3mm	1
13	SZL 322x 97 x12mm	1
14	SZH 284x 97 x12mm	1
15	SZL 322x 97 x12mm	1
16	RW 590x318x3mm	1




A7	15mm	2x
b3	KA37	2x
c	kurz 6,3x11	4x
e7	Gleiter	3x
e11	24,3	11x
f8	246 Auszug	2x
n	8x30mm	8x
s3	4x21	4x
s6	4x27	4x
v		2x
x	Ø=40mm	4x
y4	Leim	1x
h		1x

A7	15mm	2x	l	20x				
b3	KA37	2x	l1	12x				
c	kurz 6,3x11	4x	n	8x30mm	18x	h	1x	
e7	Gleiter	3x	q10	M4x9	2x	x	Ø=40mm	4x
e11	24,3	11x	s3	4x21	4x	y4	Leim	1x
f1		11x	s6	4x27	4x	y14		8x
f8	246 Auszug	2x	v		2x	z		10x




1




l		14x
ll		12x

4

q10		2x
-----	--	----




2



f1		11x
n	8x30mm	10x

3



l		6x
y14		2x
z		10x

5

