



Art. Nr

59660402; 49089712




Art. Nr













68306420; 59473620

LKZ 40947



D	Montageanleitung	GB	Assembly instructions
FR	Notice de montage	IT	Istruzioni di montaggio
NL	Handleiding voor de montage	PL	Instrukcja montażu
CZ	Montážní návod	SK	Návod na montáž
HU	Szerelési útmutató	RO	Instrukțiuni de montaj
TR	Montaj talimatı	RU	Инструкция по монтажу








68306420; 59473620

Nº	Size/MaB (mm)	Qty	✓	Nº	Size/MaB (mm)	Qty	✓
1	420x70x70	2		8	932x76x18	2	
2	420x70x70	2		9	582x76x18	2	
7	1100x750x24	1		10	1020x670x15	1	



59660402; 49089712

Nº	Size/MaB (mm)	Qty	✓	Nº	Size/MaB (mm)	Qty	✓
1	420x70x70	2		8	582x76x18	2	
2	420x70x70	2		9	582x76x18	2	
7	750x750x24	1		10	670x670x15	1	



4

J 250012
3,5x15 x8



5

H 070045
Home x1

