













<p>Ax1</p> 	<p>Bx1</p> 	<p>Cx1</p> 	<p>Dx1</p> 
<p>Ex4</p>  <p>M6X16MM</p>	<p>Fx1</p> 		
<p>1</p> 		<p>2</p> 	
<p>3</p> 		<p>4</p> 	



- (D)** Bitte überprüfen Sie in regelmäßigen Abständen den festen Sitz der Schrauben!
- (GB)** Please check the screws for tightness at regular intervals!
- (F)** Veuillez contrôler régulièrement que les vis sont convenablement serrées !
- (ES)** ¡Compruebe periódicamente que los tornillos estén bien apretados!
- (IT)** Controllare regolarmente che le viti siano ben strette!
- (PL)** Należy regularnie sprawdzać dokręcenie śrub!
- (NL)** Controleer op regelmatige afstanden of de schroeven goed vast zitten.
- (SWE)** Kontrollera med jämna mellanrum att skruvarna sitter fast ordentligt!
- (SK)** V pravidelných intervaloch kontrolujte pevné dotiahnutie skrutiek!
- (SL)** Redno preverjajte, ali so vijaki trdno priviti!
- (HR)** Redovito provjeravajte čvrsto nalijeganje vijaka!