




MARLA RB 180



- DE

Montageanleitung
- PL

Instrukcja montażu
- NL

Handleiding voor de montage
- GB

Assembly instructions
- TR

Montaj talimatı
- RU

Инструкция по монтажу

IT

Istruzioni di montaggio

FR

Notice de montage

RO

Instrucțiuni de asamblare

SK

Montážny návod

CZ


Montážní návod







HU

Szerelési útmutató

Name - Nazwa - Naam - Name - Isim - название
Nome - Nom - Numele - Meno - Jméno - Neve


MARLA RB 180




								
4x	12x (M8x40)	8x (M6x20)	2x (M6x35)	8x (M6x50)	2x	2x		
								
a	b	c	d	e	f	g		
2x	2x	2x Ø35	2x (Ø6)	12x (Ø8)				
								
i	j	k	m	n				
								

Service - Servis - Dienstverlening - Servis - Serwis - Сервисная служба - Servizio - Service
Serviciu - Služby - Szolgáltatás


COLLI 1



COLLI 2




COLLI 3




Ver: 25.09.25



1




2



7




3






4

2x



5

2x



6

