









Service•Assistenza•Dienstverlening•Serwis Servis•Serviz•Сервисная служба

Name• Nom • Nome • Naam •
Nazwa•Jméno• Názov•Név•
Denumire•İsim •Название

Nr. • No. • N° •Номер•Cz

14868023,35603739

Typ• Type• Tip•
Tipus• Tipo•Тип•





- (D) Montageanleitung
- (FR) Notice de montage
- (NL) Handleiding voor de montage
- (CZ) Montážní návod
- (HU) Szerelési útmutató
- (TR) Montaj talimatı

- (GB) Assembly instructions
- (IT) Istruzioni di montaggio
- (PL) Instrukcja montażu
- (SK) Návod na montáž
- (RO) Instrucţiuni de montaj
- (RU) Инструкция по монтажу
- (HR) Shema montaže



Art.Nr. 756574, 757021
LKZ 40827



30 min





1.




A Metalleinbauelemente (der Metallstift) in den Fuß einsetzen

2.




x4

GEWINDESCHRAUBE MUSS VÖLLIG
EINGESCHRAUBT WERDEN!



x4

3.



4.

