





Hamilton



- | | | | |
|----|------------------------|----|-----------------------------|
| D | Montageanleitung | GB | Assembly instructions |
| FR | Notice de montage | NL | Handleiding voor de montage |
| CZ | Montážní návod | IT | Istruzioni di montaggio |
| RO | Instructiuni de montaj | RU | инструкция по сборке |
| PL | Instrukcja montazu | SK | Návod na montáž |
| HU | Szerelési útmutató | TR | Montaj talimati |



Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam
Nazwa • Jméno • Názov • Név
Denúire • Ísim • Название




**Hamilton
DB**

Nr. • No. • N° • Номер • Č • Sz

SH42

Typ • Type • Tip • Típus • Тип
Тип




OHNE



A	B	C	D	E	F	G	H
4x	1x 6x45	1x M6	1x M6	1x M6	2x 8x60	2x M8	2x M8


Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба


Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denúire • Ísim • Название	Hamilton DB
Nr. • No. • N° • Номер • Č • Sz	SH42
Typ • Type • Tip • Típus • Tipo Тип	LARO



A	B	C	D	E	F	G	H
4x	1x 6x45	1x M6	1x M6	1x M6	2x 8x60	2x M8	2x M8



A	B	C	D	E
				
4x	1x 6x45	1x M6	1x M6	1x M6





F	H	
		
2x 8x60	2x M8	2x M8

