



(D) Montageanleitung

(TR) Montaj talimatı

(RU) Инструкция
по монтажу

(RO) Instrucțiuni
de montaj

(GB) Assembly instructions

(IT) Istruzioni di
montaggio

(CZ) Montážní návod


(PL) Instrukcja montażu

(FR) Notice de montage

(NL) Handleiding voor
de montage

(HU) Szerelési útmutató





(SK) Návod na montáž



0203_03R Rollcontainer


REPC-Nr.:

Service • Assistenza • Dienstverlening • Servis
Servis • Szerviz • Сервисная служба




Colli 1/1: (1) (2) (3) (4) (5) (6) (7) (8) (9) (10) (11) (12) Beutel 1/2, 2/2

Beutel 1/2










1-10		1-37		1-122		1-190		1-200		1-330	
4x	6,3x50	1x	4,5x25	16x	4x13	6x	M4x20	18x	6,3x13	6x	M4x10
2-10		2-20									
4x		4x									

Beutel 2/2

3-130		5-130		6-401	
6x		2x		3x	



Colli 1/1

											
1x	1x	1x	1x	1x	3x	3x	3x	3x	3x	6x	4x
449 x 444	418 x 426	418 x 426	430 x 430	449 x 426	446 x 140	396 x 380	386 x 80	380 x 80	380 x 80	Metall	

