








- | | |
|----------------------------------|------------------------------|
| (D) Montageanleitung | (RO) Instrucțiuni de montaj |
| (GB) Assembly instructions | (CZ) Montážní návod |
| (FR) Notice de montage | (TR) Montaj talimatı |
| (NL) Handleiding voor de montage | (IT) Istruzioni di montaggio |
| (HU) Szerelési útmutató | (SK) Návod na montáž |
| (PL) Instrukcja montażu | (RU) Инструкция по монтажу |

Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam •
Nazwa • Jméno • Názov • Név •
Denumire • Ísim • Название

Nr. • No. • N° • Номер • Č • Sz

Typ • Type • Tip • Típus • Tipo •
Тип







1	1x	ca. 850 x 350 mm
2	1x	ca. 831 x 358 mm
3	1x	ca. 819 x 330 mm
4	1x	ca. 438 x 330 mm
5	1x	ca. 346 x 315 mm

6	1x	ca. 438 x 330 mm
7	2x	ca. 819 x 77 mm
8	1x	ca. 196 x 310 mm
9	1x	ca. 608 x 310 mm
10	1x	ca. 638 x 357 mm









A 8,0 x 30 mm 12x	B 12x	C 12x	D 1x	E 4,0 x 13 mm 2x	F 2x
G 3,5 x 13 mm 12x	H 2x	I 2x	J 8x	K 2,7 x 20 mm 4x	L 4x
					M 3,0 x 40 mm 6x

1









A	8,0 x 30 mm	C		4x
B				8x
I				h=2 2x
M	3,0 x 40 mm			6x






2

A 8,0 x 30 mm 8x	B 4x	C 8x
F 200 mm 2x	G 3,5 x 13 mm 6x	






3




D 1x	E 4,0 x 13 mm 2x
H Ø35 Kr.0 2x	



4






5




MA1

6 **G** 3,5 x 13 mm **6x**



- (D) **Bremsekraft einstellen**
- (GB) **Adjust brake force**
- (FR) **Réglez la force de freinage**
- (IT) **Regola la forza frenante**
- (NL) **Pas de remkracht aan**
- (PL) **Dostosuj siłę hamowania**
- (CZ) **Seříd'te brzdnou sílu**
- (RO) **Reglați forța de frână**
- (HU) **Állítsa be a fékerőt**
- (SK) **Nastavte brzdnú silu**
- (TR) **Fren gücünü ayarlayın**
- (RU) **Отрегулируйте тормозное усилие**

- (D) **Türen einstellen**
(Scharniere justieren)
- (GB) **Adjusting the doors**
(adjusting the hinges)
- (FR) **Régler les portes**
(ajuster les charnières)
- (IT) **Sistemare le porte**
(regolare le cerniere)
- (NL) **Deuren instellen**
(scharnieren afstellen)
- (PL) **Nastawić drzwi**
(wyregulować zawiasy)
- (CZ) **Vyrovnejte dvířka**
(seříd'te závěsy)
- (RO) **Nastavenie dverí**
(nastavenie závesov)
- (HU) **Állítsa be az ajtókat**
(állítsa be a zsanérokat)
- (SK) **Reglare uși**
(ajustare balamale)
- (TR) **Kapıların ayarlanması**
(menteselerin seviye ayarı)
- (RU) **Регулировка дверей**
(регулировка шарнира)



- (D) Türen einstellen
(Scharniere justieren)
- (GB) Adjusting the doors
(adjusting the hinges)
- (FR) Régler les portes
(ajuster les charnières)
- (IT) Sistemare le porte
(regolare le cerniere)
- (NL) Deuren instellen
(scharnieren afstellen)
- (PL) Nastawić drzwi
(wyregulować zawiasy)

- (CZ) Vyrovnajte dvířka
(seřid'te závěsy)
- (RO) Nastavenie dverí
(nastavenie závesov)
- (HU) Állítsa be az ajtókat
(állítsa be a zsanérokat)
- (SK) Reglare uši
(ajustare balamale)
- (TR) Kapıların ayarlanması
(menteşelerin seviye ayarı)
- (RU) Регулировка дверей
(регулировка шарнира)

