







D Montageanleitung**GB** Assembly instructions**NL** Handleiding voor de montage**PL** Instrukcja montażu**HU** Szerelési útmutató**RO** Instrucțiuni de montaj**FR** Notice de montage**IT** Istruzioni di montaggio**CZ** Montážní návod**SK** Návod na montáž**TR** Montaj talimatı**RU** Инструкция по монтажу

Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба

Name • Nom • Nomo • Naam Nazwa • Jméno • Název • Név Denumire • Isim • Название	MZ
Nr. • No. • N° • Номер • C • Sz Typ • Type • Tip • Tipus • Tipo Typ	9.6101







1.	ASL 705x460x15mm	1
2.	ASR 705x460x15mm	1
3.	BL 1200x500x15mm	1
4.	MS 705x460x15mm	1
5.	RWL 704x265x15mm	1
6.	SDK 265x93x15mm	1
7.	AZ 232x430x15mm	1
8.	TRA 880x157x15mm	1
9.	ZB 265x433x15mm	1
10.	TR 456x293x15mm	1
11.	SKV 293x141x15mm	1
12.	SKB 242x318x3mm	1
13.	SZL 322x97x12mm	1
14.	SZH 231x97x12mm	1
15.	SZL 322x97x12mm	1




A5	0mm	2x
B1	kurz 6,3x11	2x
c	6,3x19 lang	6x
c1	6,3x19	2x
e11	24,3	10x
f8	246 Auszug	2x
n	8x30mm	16x
s6	4x27	4x
t	3,5x13	4x
v		2x
z8		2x
g13	Rollschub-führung Rechts 400mm	1x
g14	Rollschub-führung Links 400mm	1x
y4	Leim	1x

A5	0mm	2x	l	4x	d5		1x
B1		2x	l1	4x	g13	Rollschub-führung Rechts 400mm	1x
c	kurz 6,3x11	6x	n	8x30mm	22x		
c1	6,3x19 lang	2x	q10	M4x9	2x	g14	Rollschub-führung Links 400mm
e11	24,3	10x	s6	4x27	4x		
f1		10x	t	3,5x13	4x	y4	Leim
f8	246 Auszug	2x	v		2x	z8	




1

l		4x
l1		4x




3

f1		6x
n		6x




5

d5		1x
----	---	----



2

f1		4x
----	--	----



4

q10		2x
-----	---	----

