








- | | |
|----------------------------------|------------------------------|
| (D) Montageanleitung | (FR) Notice de montage |
| (NL) Handleiding voor de montage | (CZ) Montážní návod |
| (HU) Szerelési útmutató | (TR) Montaj talimatı |
| (GB) Assembly instructions | (IT) Istruzioni di montaggio |
| (PL) Instrukcja montażu | (SK) Návod na montáž |
| (RO) Instrucțiuni de montaj | (RU) Инструкция по монтажу |

Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam •
Nazwa • Jméno • Názov • Név •
Denumire • Ísim • Название



Nr. • No. • N° • Номер • Č • Sz



Typ • Type • Tip • Típus • Tipo •
Тип




A 8,0 x 30 mm 16x	B 16x	C 16x	D 6x	E 3,0 x 12 mm 12x	F 6x	G 4,0 x 20 mm 6x
H 4x	I 4x	J M4,0 x 9 mm 4x	K 2,7 x 20 mm 12x	L 4x	M 6,3 x 13 mm 8x	N 1x
O 8x						

1




A 8,0 x 30 mm  16x	B  16x	C  16x	D  6x	E 3,0 x 12 mm  12x	F  6x	G 4,0 x 20 mm  6x
L  4x	M 6,3 x 13 mm  8x					I h=2  4x





2



D Leim
GB Glue
FR Colle
IT Colla
NL Lijm
PL Klej
CZ Lepidlo
SK Glej
HU Enyv
RO Adeziv
TR Tutkal
RU Клей



3






4

0



8x





(NL) **Deuren instellen**
(scharnieren afstellen)

(D) **Türen einstellen**
(Scharniere justieren)

(GB) **Adjusting the doors**
(adjusting the hinges)

(FR) **Régler les portes**
(ajuster les charnières)

(IT) **Sistemare le porte**
(regolare le cerniere)

(PL) **Nastawić drzwi**
(wyregulować zawiasy)

(CZ) **Vyrovnejte dvířka**
(seřid'te závěsy)

(RO) **Nastavenie dverí**
(nastavenie závesov)

(HU) **Állítsa be az ajtókat**
(állítsa be a zsanérokat)

(TR) **Reglare uşi**
(ajustare balamale)

(SK) **Kapıların ayarlanması**
(menteşelerin seviye ayarı)

(RU) **Регулировка дверей**
(регулировка шарнира)

