


ANTALY WLS




- | | |
|----------------------------------|--------------------------------|
| (DE) Montageanleitung | (IT) Istruzioni di montaggio |
| (PL) Instrukcja montażu | (FR) Notice de montage |
| (NL) Handleiding voor de montage | (RO) Instrucțiuni de asamblare |
| (GB) Assembly instructions | (SK) Montážny návod |
| (TR) Montaj talimatı | (CZ) Montážní návod |
| (RU) Инструкция по монтажу | (HU) Szerelési útmutató |




8 x (8x90) m	4 x (8x60) a	12 x O8 d	12 x M8 e	9 x (4x16) f	10 x (5x35) i	8 x g
10 x 50mm 50mm r	12 x j	18x k		2x 1	4x 2	


Coli.:1




Coli.:2



Coli.:3



Coli.:4



13

