

Flair



D Montageanleitung

GB Assembly instructions

FR Notice de montage

NL Handleiding voor de montage

CZ Montážní návod

IT Istruzioni di montaggio

RO Instrucțiuni de montaj




RU инструкция по сборке

PL Instrukcja montażu

SK Návod na montáž


HU Szerelési útmutató

TR Montaj talimati



Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба


Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • İsim • Название	Flair DB	
Nr. • No. • N° • Номер • Č • Sz	SH50	
Typ • Type • Tip • Típus • Tipo Тип	BS G	




A	B	C	D	E	F
4x	12x 8x40	8x	8x 8x50	8x 8x60	8x M8



A	B	C	D
4x	4x 8x40	8x	8x 8x50







E	8x 8x60	B	8x 8x40	F	8x M8
Achtung! Schrauben nicht überdrehen FR Attention! Ne serrez pas trop CZ Dávej Pozor! Nepřetahujte RO Ai Grija! Nu strângeți PL Uważaj! Nie dokręcać zbyt mocno HU Vigyázz! Ne húzza túl					
GB Watch Out! Do not over tighten NL Let Op! Niet te vast IT Attento! Non stringere RU Осторожно! Не затягивайте SK Dávaj Pozor! Nepreťahujte TR Dikkat! Üzerinde sıkmayın					

