


EMPIRE  
2100/5031/2503  
2501/5031/2300



- |           |  |           |   |
|-----------|--|-----------|---|
| <b>D</b>  | MONTAGEANLEITUNG<br>BEDIENUNGSANLEITUNG                | <b>GB</b> | ASSEMBLY INSTRUCTIONS<br>INSTRUCTION MANUAL         |
| <b>NL</b> | HANDLEIDING VOOR DE MONTAGE<br>GEBRUIKSAANWIJZING      | <b>PL</b> | INSTRUKCJA MONTAŻU<br>INSTRUKCJA OBSŁUGI            |
| <b>TR</b> | MONTAJ TALIMATI<br>KULLANIM KLAVUZU                    | <b>RU</b> | ИНСТРУКЦИЯ ПО МОНТАЖУ<br>ИНСТРУКЦИЯ ПО ЭКСПЛУАТАЦИИ |
| <b>RO</b> | INSTRUCȚIUNI DE INSTALARE<br>INSTRUCȚIUNI DE UTILIZARE | <b>IT</b> | ISTRUZIONI DI MONTAGGIO<br>MANUALE DI ISTRUZIONI    |
| <b>FR</b> | NOTICE DE MONTAGE<br>MANUEL INSTRUCTIONS               | <b>SK</b> | MONTÁŽNY NÁVOD<br>NÁVOD NA POUŽITIE                 |
| <b>HU</b> | KÖZGYŰLÉS UTASÍTÁSOK<br>KEZELÉSI UTASÍTÁS              | <b>CZ</b> | MONTÁŽNÍ NÁVOD<br>NÁVOD K POUŽITÍ                   |
| <b>SI</b> | NAVODILA ZA MONTAŽO<br>NAVODILA ZA UPORABO             | <b>PT</b> | INSTRUÇÕES DE MONTAGEM<br>MANUAL DO USUÁRIO         |
| <b>ES</b> | INSTRUCCIONES DE MONTAJE<br>MANUAL DEL USUARIO         | <b>HR</b> | UPUTE ZA MONTAŽU<br>UPUTE ZA UPOTREBU               |




190801







**0019**




**0019**




0064







**R**










**L**










0  
10  
20  
30  
40  
50  
60  
70  
80  
90  
100  
110  
120  
130  
140  
150  
160  
170  
180  
190  
200

<b>i</b> L-5  X1	<b>d</b> M8*80  X4	<b>f</b> H-90  X4	<b>x</b> Fi-50  X4	[mm]
---	---	--	--	------




<b>i</b> L-5  X1	<b>s</b> H-90  X1	<b>f</b> H-90  X1	<b>x</b> Fi-50  X3	<b>q</b> M8*80  X3
---	--	--	---	---















90°










0019



<b>s</b> H-90	<b>i</b> L-5	<b>f</b> H-90	<b>x</b> Fi-50	<b>q</b> M8*80 [mm]
				
X1	X1	X1	X3	X3
























<b>i</b> L-5 	<b>f</b> H-90 	<b>x</b> Fi-50 	<b>q</b> M8*80 
X1	X4	X4	X4



<b>s</b> H-90 	<b>i</b> L-5 	<b>f</b> H-90 	<b>x</b> Fi-50 	<b>q</b> M8*80 
X1	X1	X1	X3	X3











Service · Dienstverlening · Servis · Servis · Сервисная служба · Serviciu · Services · Servizio  
 ·Servisný list · Szolgáltatás · Servisní list


Name · Naam · Nazwa · İsim · Название · Nume · Nome · Název · Názov ·  
 Název · Neve

**EMPIRE**


Typ · Type · Tip · Тип · Tipo · Típus



**R**



**L**



<b>i</b> L-5	<b>f</b> H-90	<b>x</b> Fi-50	<b>q</b> M8*80	<b>s</b> H-90 [mm]

