




D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage  
PL - Instrukcja montazu TR - Montaj talimatu RU - Инструкция по монтажу  
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage  
SK - Navod na monta CZ - Montážní návod HU - Szerelési utmutató



1/1





# NALO RecBK-2F



C x 2



K x 2



Service-Dienstverlening-Serwis-Servis-Сервисная служба-Assistenza-Szerviz

Typ-Type-Tip-Tipus-Tipo 302

|    |    |
|----|----|
| C  | K  |
| E1 | L1 |
| E2 | L2 |
| G1 | L3 |
| G2 |    |
| H  |    |
| J  |    |

