

- D

Montageanleitung
- GB

Assembly instructions
- NL

Handleiding voor de montage
- PL

Instrukcja montażu
- HU

Szerelési útmutató
- RO

Instrucțiuni de montaj
- FR

Notice de montage
- IT

Istruzioni di montaggio
- CZ

Montážní návod
- SK

Návod na montáž
- TR

Montaj talimatı
- RU













Инструкция по монтажу

Service • Assistenza • Dienstverlening • Serwis

Servis • Szerviz • Сервисная служба





Name • Nom • Nome • Naam Nazwa • Jméno • Mäzox • Név Делителка • Işim • Название	ST
Nr. • No. • N° • Номер • C. • Sz	
Typ • Type • Тип • Típus • Tipo	9.8215

1.	ASL 708x550x15mm	1
2.	ASR 735x550x15mm	1
3.	MS 708x550x15mm	1
4.	BL 1250x600x15mm	1
5.	BD 350x550x15mm	1
6.	ZB 318x515x15mm	1
7.	EB 318x515x15mm	1
8.	TRA 846x253x15mm	1
9.	TR 574x314x15mm	1
10.	RW 590x318x3mm	1




A7	15mm	2x
B1	Gleiter	2x
e7	24,3	3x
e11	4x21	9x
s3	4x27	4x
s6	4x27	2x
V		1x
X	Ø=40mm	4x

A7	15mm	2x	l1	8x
B1	Gleiter	2x	n	10x
e7	24,3	3x	r	4x
e11	4x21	9x	s3	4x
f1	4x27	9x	s6	2x
l		14x	v	1x
			z	10x




1




l		8x
l1		8x
h4		2x

4

r		4x
---	--	----




2



f1		9x
n		10x

3



l		6x
y14		2x
z		10x

