






- | | | | |
|----|-----------------------------|----|-------------------------|
| Ⓓ | Montageanleitung | ⒼⒷ | Assembly instructions |
| ⒻⓇ | Notice de montage | ⒾⓉ | Istruzioni di montaggio |
| ⓃⓁ | Handleiding voor de montage | ⓅⓁ | Instrukcja montażu |
| ⒸⓏ | Montážní návod | ⓈⓀ | Návod na montáž |
| ⒽⓊ | Szerelési utmutató | Ⓡⓞ | Instrucțiuni de montaj |
| ⓉⓇ | Montaj talimatı | ⓇⓊ | Инструкция по монтажу |

Ausgabe:20230611













Service • Assistenza • Dienstverlening • Serwis
 Servis • Szerviz • Сервисная служба®

| | |
|--|-----------|
| Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • Isim • Название | |
| Nr. • No. • N° • Номер • Č. Sz | 5009 7012 |
| Typ • Type • Tip • Típus • Tipo Тип | YS-WR7097 |






X 2


| | | | | |
|--|---|---|--|--|
| A M4X12MM  X4 | B D15  X42 | C  X42 | D D12  X8 | E  X8 |
| F M4X25MM  X8 | G M4X40MM  X16 | H  X1 | J  X4 | |




1





2

| | |
|---|-----|
| B | D15 |
|  | X2 |




3

| | |
|---|-----|
| B | D15 |
|  | X8 |




4

B D15
X18






5

B D15
X14





6

| | | | |
|---|---------|---|----|
| A | M4X12MM | H | |
|  | X4 |  | X1 |







7

| | | | | | |
|----------|---|----|----------|---------|-----|
| J |  | X4 | G | M4X40MM | X16 |
|----------|---|----|----------|---------|-----|




8

| | | | | | |
|----------|---|----------|----|---|---------|
| D | D12 | E | | F | M4X25MM |
| |  | | X8 |  | X8 |
| | | | |  | X8 |



X 2



9

