







- | | | | |
|----|-----------------------------|----|-------------------------|
| Ⓓ | Montageanleitung | ⒼⒷ | Assembly instructions |
| ⒻⓇ | Notice de montage | ⒾⓉ | Istruzioni di montaggio |
| ⓃⓁ | Handleiding voor de montage | ⓅⓁ | Instrukcja montażu |
| ⒸⓏ | Montážní návod | ⓈⓀ | Návod na montáž |
| ⒽⓊ | Szerelési utmutató | ⓇⓄ | Instrucțiuni de montaj |
| ⓉⓇ | Montaj talimatı | ⓇⓊ | Инструкция по монтажу |

Ausgabe: 20211102











Service • Assistenza • Dienstverlening • Servis Servis • Szerviz • Сервисная служба		
Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • İsim • Название	THORNTONCT1	
Nr. • No. • N° • Номер • Č • Sz	22337247 / 89753349	
Typ • Type • Tip • Tipus • Tipo Тип	YS-CT3061	



A 1/4X32MM X1	B X1	C D15 X15	D X15	E D12 X8	F X8
G M4X25MM X8	H X2	I M4X15MM X2	J X5	K 8#X25MM X4	




1




2

C	D15	
		X1
J		X1





3



A	1/4X32MM	
		X1
B		X1
J		X1



4




5




6

C	D15	J
	X8	
		X1



7



E	D12	F	G
	X8		
		X8	X8
H		I	
	X2		
		X2	

